

## HIGH PERFORMANCE FOR YOUR RENOVATION

RENOVATION WALL TILE & PANELLING has been specially developed to renovate high traffic surfaces, even inside a shower.

The Aquaresist technology creates a durable, waterproof barrier that resists condensation and repeated water splashing.









- 2 in 1: no undercoat.
- ➤ HIGH RESISTANCE to care and maintenance products: shampoos, shower gels, classic household products, anti-limescale products, diluted bleach, white vinegar...
- > RESISTANT to repeated water splashing.
- Does not flake: high paint film resistance to temperature variations: hot water, cold water.
- **Easy application: perfect finish.**
- Ultra washable: easy maintenance.

# **COLOURCHART** – satin aspect













# NO UNDERCOAT NO STRIPPING

Drying time:

Recoat: **6h** - Fully dry: **24h** Tool cleaning: **water** 

**COVERAGE:** 

 $750ml = +/- 10m^2 - 2L = +/- 24m^2$ 

This paint has been specially developed for wall tiles made of ceramic, glass bricks and PVC paneling; varnished, painted or raw woods. It is suitable for tiled shower cubicles.

This paint is not a sealant. Do not apply on sinks, bathtubs or floors.

#### **TOOLS:**

- Paint stirrer or wide stick
- 4-5mm short pile roller
- Round edeged paint brush (for angles, corners & finishes)



#### PREPARATION:

PREPARATION of the surface is ESSENTIAL

WASH the surface with a sodabased or sugar soap (alkaline) cleaner, focusing on the grouting.

- CERAMIC TILES, WALL TILES, BORDER TILES, GLASS BRICKS: wash, rinse thoroughly with water then allow to dry.
- **PANELLING:** wash, rinse thoroughly with water then allow to dry. Lightly sand with 240 grit sandpaper and remove dust.
- **TILE GROUTING:** Carefully clean the tile grouting with an abrasive sponge or brush to remove any residual cleaning products or any traces of mould.

Remove any silicone sealant before painting. Reseal after application of the paint.

## **APPLICATION:**

Apply the paint at room temperature between 12 and 25°C and avoid draughts.

- 1. Empty the additive (the sachet that is placed under the lid of the tin) into the paint. Stir the paint for 5 minutes, working around the bottom of the tin with a wide stick to mix it well.
- 2. Work on small surfaces. Apply from one end to the other. Follow with successive cross strokes. Do not start 2nd coat while it's still drying. Leave to dry for 6h and apply a 2nd coat in the same way. A 3rd coat may be required depending on the surface and colour.

Once the sachet has been added, the mixture must be used within 10 days to maintain optimal adhesion and performance.

#### V33 TIPS:

To clean your painted surfaces, use a gentle detergent and a non-abrasive sponge.

Optimum product performance and adhesion is achieved after 20 days from application. Treat the surface gently, avoiding direct impact, abrasion, staining or cleaning, for the first 20 days after application.







